

## MAINTENANCE

# MAINTENANCE SCHEDULE

Perform the PRE-RIDE INSPECTION in the Owner's Manual at each scheduled maintenance period.

I: Inspect and clean, adjust, lubricate or replace if necessary. C: Clean. R: Replace. A: Adjust. L: Lubricate.

The following items require some mechanical knowledge. Certain items (particularly those marked \* and \*\*) may require more technical information and tools. Consult your Honda dealer.

ITEMS			FREQUENCY	NOTE ↓	ODOMETER READING (NOTE 1)						REFER TO PAGE	
					x 1,000 mi	4	8	12	16	20		24
					x 1,000 km	6.4	12.8	19.2	25.6	32.0		38.4
EMISSION RELATED ITEMS	*	FUEL LINE				I		I		I	3-5	
	*	THROTTLE OPERATION				I		I		I	3-5	
	*	AIR CLEANER	NOTE 2				R			R	3-6	
		CRANKCASE BREATHER	NOTE 3		C	C	C	C	C	C	3-7	
		SPARK PLUG		EVERY 16,000 mi (25,600 km) R						3-8		
	*	VALVE CLEARANCE	NOTE 4	EVERY 32,000 mi (51,200 km) I						3-9		
		ENGINE OIL		R		R		R		3-11		
		ENGINE OIL FILTER		R		R		R		3-12		
		RADIATOR COOLANT	NOTE 5		I		I		R	3-13		
	*	COOLING SYSTEM			I		I		I	3-14		
	*	SECONDARY AIR SUPPLY SYSTEM			I		I		I	3-14		
NON-EMISSION RELATED ITEMS	*	EVAPORATIVE EMISSION CONTROL SYSTEM				I			I	3-15		
		FINAL DRIVE OIL			I		I		R	3-15		
		BRAKE FLUID	NOTE 5		I	I	R	I	I	R	3-16	
		BRAKE PAD WEAR			I	I	I	I	I	I	3-17	
		BRAKE SYSTEM			I		I		I	3-18		
	*	BRAKE LIGHT SWITCH			I		I		I	3-18		
	*	HEADLIGHT AIM			I		I		I	3-19		
		CLUTCH SYSTEM			I		I		I	3-19		
		CLUTCH FLUID	NOTE 5		I	I	R	I	I	R	3-19	
	*	REVERSE OPERATION			I		I		I	3-20		
		SIDE STAND			I		I		I	3-20		
	*	SUSPENSION			I		I		I	3-21		
	*	NUTS, BOLTS, FASTENERS			I		I		I	3-21		
	**	WHEELS/TIRES			I		I		I	3-22		
	**	STEERING HEAD BEARINGS			I		I		I	3-22		

\* Should be serviced by your dealer, unless the owner has proper tools and service data and is mechanically qualified.

\*\* In the interest of safety, we recommend these items be serviced only by your Honda dealer.

### NOTES:

- At higher odometer readings, repeat at the frequency interval established here.
- Service more frequently when riding in unusually wet or dusty areas.
- Service more frequently when riding in rain or at full throttle.
- Service more frequently if noisy.
- Replace every 2 years, or at the indicated odometer interval, whichever comes first. Replacement requires mechanical skill.